

Instructions to Wire APC SU1400RMNET Battery Pack

- (1) Line up four 12V batteries and use double-sided tape to hold them together.
- (2) Attach the two battery fuses to the battery pack as pictured. Note: each fuse connects a negative terminal to a positive terminal as follows:
 - a. Fuse # 1 will connect the negative of the 1st battery to the positive to the 3rd battery.
 - b. Fuse #2 will connect the negative of the 2nd battery to the positive of the 4th battery.
- (3) Connect the two positive connectors from the UPS to the two remaining positive connectors on batteries 1 and 2, while connecting the two remaining negative connectors from the UPS the batteries 3 and 4.

